



2-Button Remote Control

Access transmitters are used with garage door or gate that are 315Mhz. This model A315 can be used with either one or two garage doors and gate operators. To program, locate the purple learn button on the powerhead of your door operator. The code between the remote control and the receiver changes with each use.

⚠ WARNING

- Moving door can cause serious injury or death
- Always keep people clear of opening while door is moving
 - Always keep remote control out of reach of children. Never permit children to operate or play with remote
 - Activate gate or door only when it can be seen clearly and there are no obstructions to door travel

PROGRAMMING THE REMOTE CONTROL

1 Locate the Smart/Learn button.

2 Press and immediately release the learn button. The learn LED will glow steadily for 30 seconds.

3 Press and hold the button on the remote control that you wish to use. "click" "click" Release the button when the garage door opener lights blink or two clicks are heard.

Erasing all receiver memory.

1 Press and hold the learn button on garage or gate operator for approximately 5 seconds until the learn button LED goes out. All previous codes are erased from receiver memory. Reprogram each remote control you wish to use.

Replacing battery (programming is not affected by replacing battery)

1 Use the visor clip or screwdriver to open the cover

2 Remove the old battery. Dispose of old batteries properly. 12V Size: 23A

3 Insert replacement batteries ⊕ right side. Replace the batteries with only 12V / 23A Alkaline batteries

4 Replace cover

General specification & Feature:

1. Output Power: -37dBm
2. Output Frequency: 315MHz
3. Power Supply: 12Vdc(5Vdc Regulation)
4. Visor clip

Caution

Any changes or modifications of this device which are not expressly approved by the party responsible could void the user's warranty.

DISTRIBUTED BY

Export Management System Inc.
Hawthorne CA 90250 USA