


INSTALLATION INSTRUCTIONS COAXIAL ANTENNA KIT MODEL DC-5166 \ DC-5168

The Coaxial Antenna Kit permits the remote location of the antenna on radio receivers equipped with a type F connector. The antenna can be moved away from a metal structure or to an outside location for better receiver performance.

Refer to the appropriate receiver and transmitter installation instructions for mounting and connecting to the door operator.

Locate and mount the antenna bracket securely at the desired location making sure the coaxial cable will not interfere with the operation of the power unit. Screw the antenna onto the receptacle at the bracket. Plug the cable onto the receiver antenna connector.



It is recommended that the cable be protected by a rubber grommet, at the point where it passes through the structure.

Digi-Code, Inc. 307 Robbins Dr. Troy, Michigan 48083

Part # 72-5166