# Transmitter Solutions Firefly3™ Type: FIRIII390LMD21K3 FCC ID: SU7FIR390LMD21K3

This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept interference received, including interference that may cause undesired operation.

### NOTICE

Any changes or modifications to Transmitter Solutions equipment not expressly approved by Transmitter Solutions could void the manufacturer's warranty and could void the user's authority to operate the equipment.

### WARRANTY

The warranty period of Transmitter Solutions Firefly3<sup>TM</sup> transmitters is twenty-four (24) months. This warranty shall begin on the date the transmitter is manufactured. During the warranty period, the product will be repaired or replaced (at the sole discretion of Transmitter Solutions) if the product does not operate correctly due to a defective component. This warranty does not extend to (a) the transmitter case, which can be damaged by conditions outside the control of Transmitter Solutions, or (b) battery life of the transmitter. This warranty is further limited by the following disclaimer of warranty and liability:

EXCEPT AS SET FORTH AGOVE, TRANSMITTER SOLUTIONS MAKES NO WARRANIES REGARDING THE COODS, EVERESS OR IMPLIED, INCLUDING WARRANITY OF MERCHANTIBUILTY OR WARRANITY OF FITNESS FOR A PARTICULAR PURPOSE. BUYER MAKES NO RELIANCE ON ANY REPRESENTATION OF TRANSMITTER SOLUTIONS, EVERESS OR IMPLIED, WITH REGARD TO THE GOODS AND ACCEPTS THEM "ASSIS/MHERES". TRANSMITTER SOLUTIONS SELLS THE GOODS TO BUYER ON CONDITION THAT TRANSMITTER SOLUTIONS WILL HAVE NO LIABILITY OF ANY KIND AS A RESULT OF THE SALE. BUYER AGREES THAT TRANSMITTER SOLUTIONS HALL HAVE NO LIABILITY FOR DAMAGES OF ANY KIND, WHETHER DIRECT, INCIDENTIAL OR CONSEQUENTIAL DAMAGES, INCLUDING INJURIES TO PERSONS OR PROVERTY, TO BUYER, ITS EMPROYEES OR AGENTS, AS A RESULT OF THE SALE. BUYER ALSO AGREES TO THOUS TRANSMITTER SOLUTIONS HARMLESS FROM ANY CLAMIS BUYER, OR ANY THIRD BARTY, MAY HAVE AS A RESULT OF BUYER'S USE OR DISPOSAL OF THE GOODS, BUYER HAS BEAD THIS DISCLAIMER AND AGREES WHO THE SERMIS LIFENS IN CONSEQUENTIAL OF GOODS.



3788 West 2270 South, Suite E
Salt Lake City, UT 84120
(866) 975-0101 • (866) 975-0404 FX

# Manual - 390 1 Button Transmitter Solutions Firefly 3 TRANSMITTER

Thank you for choosing a Transmitter Solutions product.

Please read this manual carefully before using the product.

Made in Taiwan. Copywrite © 2015 Transmitter Solutions.

# CONTENTS

# 1 - TRANSMITTER OVERVIEW

1A - General information

1B - Technical specifications

1C - Main components

2 - NUMBERING

3 - PROGRAMMING

4 - OPERATION

5 - BATTERY ACCESS

6 - TROUBLESHOOTING

## 1A - General information

The Transmitter Solutions- Firefly3<sup>TM</sup> Transmitter is a very small (1-1/2"  $\times$  2-1/8"  $\times$  3/8") key chain style wireless transmitter operating at 390 MHz. The Firefly<sup>TM</sup> achieves its small size by using state-of-the-art, surface mount components. It has been designed for use with and is compatible with all  $Liftmaster^{60}$  dip switch receivers operating at a 390 frequency.

Liftmaster is a registered trademark owned by the Chamberlain Group.

### 2 - CODING

Set the nine-digit toggle code switch to match the code set from another functioning transmitter. Access to the Firefly stoggle code switch is achieved by removal of the back cover and battery (if necessary). Move switches using a small pointed object, such as a paper dip, gently switching the small switches to either the ON or OFF position. (In Detail below, switches 2, 4, 7 and 9 are in the ON position.) When complete, reinstall battery and replace back cover inserting bottom clip into front groove, then replace and tighten screw.

### 3- OPERATION

Once the codes are set to match the transmitter codes, you may test the system. Ensure the gate or door is visible and clear before testing.

**Step 1.** Push the Firefly<sup>™</sup>s button from a distance of about ten feet. If the receiver activates, the switches are properly matched.

**Step 2.** Test the transmitter from several locations to discover any "blind spots" caused by interference.

### 4 - BATTERY ACCESS

Remove set screw and open case from back. Attend to proper polarity when installing or replacing battery. See "coding" for proper removal and replacement of back cover.

### 5 - TROUBLESHOOTING

# PROBLEM SOLUTION

Detail

The system does not receive the transmitter signal. The transmitter LED will not light.

The system does not receive the transmitter signal. The transmitter LED is ON.

The operating range is reduced.

Ensure clear plastic battery insulator has been removed; OR Replace the transmitter battery.

Back

Transmitter

Detail of Switches

Check to ensure the transmitter switches are coded to match your system receiver.

Replace the transmitter battery.

The A23 battery has a shelf life of about 1 year. The product fully complies with Part 15 of the FCC Regulations.

### 1B - Technical Specifications

Operating frequency: 390 MHz


Number of buttons:

Battery: 1 ea. 12V A23 Operating temperature: -20°F - 85°F

Overall dimensions:  $1-1/2 \times 2-1/8 \times 3/8$  inch

Weight: 1 oz.

# 1C - Main components



Black Case with Blue Button